

Type number index

■ Type number index (alphabetical)

Type	Name, specifications	Page
3RK1105-1□E04-0CA0	AS-i safety monitor	25
3RK1105-1□E04-2CA0	AS-i safety monitor with enhanced functionality	25
3RK1205-0BQ00-0AA3	K45F safe compact slave (actual slave)	26
3RK1802-2FB06-0GA0	Safety monitor configuration software	28
3RK1901-1AA00	Input jumper for K45F	28
3RK1901-2DA00	Mounting plate (rail/screw dual mounting) for K45F slave	22
3RK1901-2EA00	Mounting plate (exclusive screw mounting) for K45F slave	22
3RK1901-5AA00	Cable set (Safety monitor to personal computer)	28
3RP1902	AS-i safety, sealable cap	28
3RX901□-0AA00	AS-Interface communication cable, yellow (Siemens)	92
3RX902□-0AA00	External power supply AS-i cable, black (Siemens)	92
3RX9801-0AA00	M12 branch connector	90
3SF5811-0AA08	Emergency-stop pushbutton, yellow cover	26
3SF5811-0AB08	Emergency-stop pushbutton, yellow cover with protective collar	26
FC2LA-DL	DeviceNet/AS-i gateway, V2.1	36
FC2L-TL	T-link/AS-i gateway	38
FE16D-SJ13RGNE □□■	AS-i motor starter slave, standard slave	75
FL1HA-E	Addressing unit, V2.1	87
FM1D-22RQP	Terminal block type slave 2I/2O, relay output, standard slave	73
FM1D-22TPP	Terminal block type slave, 2I/2O, standard slave	73
FM2D1-04RQX	Compact terminal-block type slave, 4O, relay output, standard slave	71
FM4D-04TNX	Flat dustproof slave, 4O, standard slave	59
FM4D-22T □□	Flat dustproof slave, 2I/2O, standard slave	59
FM4D-40XX □	Flat dustproof slave, 4I, standard slave	59
FM4D1-04TNX	Slim dustproof slave, 4O, standard slave	66
FM4D1-40XXN	Slim dustproof slave, 4I, standard slave	66
FM4DB-03TNX	Flat dustproof slave, 3O, A/B slave	60
FM4DB1-03TNX	Slim dustproof slave, 3O, A/B slave	67
FM4DB1-40XXN	Slim dustproof slave, 4I, A/B slave	67
FM4DB-40XXN	Flat dustproof slave, 4I, A/B slave	60
FM4DP0-001□	Illuminated pushbutton, A/B slave	80
FM4DP0-001□S	Illuminated pushbutton with spotlight, A/B slave	80
FM4DP2-GR1□	7-segment display, green 10's digit, red 1's digit, standard slave	79
FM4DP2-GR1□S	7-segment display with spotlight, green 10's digit, red 1's digit, standard slave	79
FM4DP2-RR1□	7-segment display, red 10's digit, red 1's digit, standard slave	79
FM4DP2-RR1□S	7-segment display with spotlight, red 10's digit, red 1's digit, standard slave	79
FM6A11-20	Waterproof slave (analog), current input	54
FM6A21-20	Waterproof slave (analog), voltage input	54
FM6A31-02	Waterproof slave (analog), current input	54
FM6A41-02	Waterproof slave (analog), voltage input	54
FM6A51-20	Waterproof slave (analog), resistance bulb input	54
FM6B1-04□□	Mounting plate, rail/screw dual mounting	44
FM6B2-04□□	Mounting plate, exclusive screw mounting	44
FM6D1-04T□X	Flat waterproof slave, 4O, standard slave	41
FM6D1-22T□□	Flat waterproof slave, 2I/2O, standard slave	41
FM6D1-40XX□	Flat waterproof slave, 4I, standard slave	41
FM6D2-04T□X	Slim waterproof slave, 4O, standard slave	49
FM6D2-22T□□	Slim waterproof slave, 2I/2O, standard slave	49
FM6D2-40XX□	Slim waterproof slave, 4I, standard slave	49
FM6DB1-03T□□	Flat waterproof slave, 3O, A/B slave	42
FM6DB1-40XX□	Flat waterproof slave, 4I, A/B slave	42
FP1AA-JNW072	Power supply, AS-i communication	83
3RK1901-1KA00	Waterproof cap	90
3RX9805-0AA00	Gasket Pg11 for AS-i cable	90
FX3CAEY	AS-Interface communication cable, yellow, general-purpose (EDPM)	29
FX3CATY	AS-Interface communication cable, yellow, oil-tight use (TPE)	29
FX3CAEB	External power supply AS-i cable, Black, general-purpose (EDPM)	29
FX3CATB	External power supply AS-i cable, Black, oil-tight use (TPE)	29
FX9R031	Repeater (AS-i line 1 and 2 isolated)	85
FX9R032	Extender (AS-i line 1 and 2 not isolated)	85
FX9Y002	Addressing cable	87
NB6P26T-14	AS-i master, NB6 basic unit	34
NJ-ASL	AS-Interface master, FLEX-PC NJ series	33
NP1L-AS1	AS-Interface master, MICREX-SX series, V2.0	32
NP1L-AS2	AS-Interface master, MICREX-SX series, V2.1	30