


Earth Leakage Circuit Breakers Dimensions SG series/3-pole


■ Dimensions, mm

● Front mounting, front connection


SG33C □ -CE, 53C □ -CE, 53RC □ -CE



SG63C □ -CE, 63RC □ -CE



SG103C □ -CE




Earth Leakage Circuit Breakers Dimensions SG series/3-pole


■ Dimensions, mm

● Front mounting, front connection

SG603RC



SG803RC




Earth Leakage Circuit Breakers Dimensions EG series/2, 3-pole


■ Dimensions, mm

● Front mounting, front connection


EG32AC □ -CE, 52AC □ -CE



EG33AC □ -CE, 53AC □ -CE, 33C □ -CE, 53C □ -CE



EG63C □ -CE



Earth Leakage Circuit Breakers


Dimensions

EG series/2, 3-pole


■ Dimensions, mm

● Front mounting, front connection


EG103AC □ -CE, 102C □ -CE, 103C □ -CE



EG203C □ -CE



EG403C □ -CE




Earth Leakage Circuit Breakers Dimensions EG series/3-pole, 4-pole


■ Dimensions, mm

● Front mounting, front connection

EG603C



EG803C



EG104A

