

Air Circuit Breakers

DA series

Ordering information

■ Type number nomenclature

DA 50 3 X A - M CLAL f
① ② ③ ④ ⑤ ⑥ ⑦ ⑧

- ① Basic type
- ② Frame size
50: 5000A 60: 6000A
- ③ Numbers of poles
2: 2-pole 3: 3-pole 4: 4-pole
- ④ Installation
X: Draw-out with cradle
Q: Draw-out with cradle and shutter
- ⑤ Series
- ⑥ Closing mechanism
T: Manual-springs
M: Motor charging springs
(Specify operating voltage)
- ⑦ Combination of overcurrent tripping device and indicator
For general feeder circuit
CLAL, CLGL
For generator protection
CSAL, CSAS
Note: Specify rated primary current (I_{cr}) and control voltage
- ⑧ Tripping device
f: Shunt trip (Specify control voltage)
r: Undervoltage trip